



AC93450OL

| No | Description | No | Description |
|----|-------------------------|----|----------------------|
| 1 | screw | 36 | fan B |
| 2 | connecting hose cover | 37 | air filter |
| 3 | connecting hose | 38 | cylinder cover elbow |
| 4 | spring gasket | 39 | inlet pipe |
| 5 | cylinder head screw | 40 | capacitor |
| 6 | cylinder head cover | 41 | capacitor screw |
| 7 | cylinder head seal ring | 42 | rubber mat |
| 8 | pan head screw | 43 | M6 flange screw |
| 9 | limiting block | 44 | Non return valve |
| 10 | air inflow valve plate | 45 | magnetic valve |
| 11 | valve plate | 46 | circuit protector |
| 12 | cylinder seal ring | 47 | protector knob |
| 13 | metal strengthen sheet | 48 | tank |
| 14 | pressure plate screw | 49 | M10 screw |
| 15 | cylinder | 50 | spring washer |
| 16 | pressure plate screw | 51 | flat gasket |
| 17 | piston | 52 | wheel |
| 18 | piston cup | 53 | flat gasket |
| 19 | connecting rod | 54 | wheel screw |
| 20 | connecting rod screw | 55 | drain valve |
| 21 | fan cover | 56 | nut |
| 22 | fan cover screw | 57 | washer |
| 23 | fan spring | 58 | rubber mat |
| 24 | fan A | 59 | rubber mat screw |
| 25 | crank | 60 | cable & plug |
| 26 | bearing 6006 | 61 | pressure gauge 50 |
| 27 | crank case A | 62 | pressure gauge 40 |
| 28 | bearing 6203 | 63 | outlet |
| 29 | rotor | 64 | regulator |
| 30 | M5 flange screw | 65 | connecting |
| 31 | stator | 66 | safety valve |
| 32 | screw | 67 | pressure switch |
| 33 | spring washer | | |
| 34 | cable buckle | | |
| 35 | crank case B | | |

AC93450OL-EX-20210705