



## AG1014P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FLANGE NUT	28	SCREW
2	POLISHING & GRINDING WHEEL	29	STATOR
3	GUARD	30	TENSION SPRING
3-1	BOLT	31	HOUSING
3-2	NUT	32	LABEL
4	FLAT KEY	33	NAMEPLATE
5	SPINDLE	34	BRUSH HOLDER
6	ANTI-DUST COVER	35	CARBON BRUSH
7	SCREW	36	BRUSH HOLDER COVER
8	SPRING WASHER	38	CORD GUARD
9	FRONT COVER	39	CORD&PLUG
10	BEAIRNG 6201Z	40	VARIABLE SPEED SWITCH
11	CIRCLIP	41	RIVET
12	WOODRUFF KEY	42	SMALL SPRING
13	BIG GEAR	43	SWITCH
14	CIRCLIP	44	CORD CLAMP
15	NEEDLE BEARING HK0810	45	SCREW
16	SELF-LOCK PIN	46	CAPACITOR
17	SCREW	48	SCREW
18	SCREW	52	WRENCH 24MM
19	SPRING WASHER	53	SIDE HANDLE
20	GEAR BOX	54	ALLEN KEY
21	SPRING	55	SCREW
22	SELF-LOCK BUTTON	888	HANDLE ASSEMBLE
23	BEARING RETAINER		
24	ROTOR		
25	INSULATION WASHER		
26	BEARING 608Z		
27	BUFFLE PLATE		

ST20130704-01