



AG90181

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|----------------|-----|---------------|
| 1 | OUTSIDE FLANGE | 30 | ROTOR |
| 3 | INNER FLAGE | 31 | BEARING 608Z |
| 4 | NUT | 32 | BUSH |
| 5 | WHEEL GUARD | 33 | KEY |
| 6 | SCREW | 34 | WIND GUARD |
| 7 | SCREW | 35 | STATOR |
| 8 | SPRING WASHER | 36 | SCREW |
| 9 | WASHER | 37 | ELECTRIC RING |
| 10 | GEAR BOX COVER | 38 | HOUSING |
| 11 | SPINDLE | 39 | BRAND NAME |
| 12 | KEY | 40 | BRUSH HOLDER |
| 13 | CIRCLIP | 41 | SCREW |
| 14 | BEARING 6202Z | 42 | CARBON BRUSH |
| 15 | BEARING COVER | 43 | SPRING |
| 16 | SCREW | 44 | BRUSH CAP |
| 17 | BIG GEAR | 45 | SCREW |
| 18 | SELF-OIL BUSH | 46 | CAPACITOR |
| 19 | SIDE HANDLE | 47 | SWITCH |
| 20 | SCREW | 48 | HANDLE |
| 21 | SPRING WASHER | 49 | CORD SLEEVE |
| 22 | SPRING | 50 | CORD CLAMP |
| 23 | LOCK PIN | 51 | SCREW |
| 24 | SCREW | 52 | CORD & PLUG |
| 25 | GEAR BOX | 53 | HANDLE |
| 26 | PINION | 54 | SCREW |
| 27 | BEARING 6001Z | 55 | SCREW |
| 28 | BEARING COVER | 56 | NUT |
| 29 | FAN | | |

RU-ST20160511
VER:2.1

