



AG919CP

NO.	DESCRIPTION	NO.	DESCRIPTION
1	WOOL WHEEL	26	BEARING COVER
2	POLISHING PAD	27	SCREW
3	SPINDLE	28	ROTOR
4	KEY	29	BEARING 608Z
5	SCREW	30	WIND GUARD
6	SPRING WASHER	31	SCREW
7	WASHER	32	STATOR
8	GEAR BOX COVER	33	BEARING
9	BEARING 6201Z	34	MOTOR HOUSING
10	BEARING COVER	35	CARBON BRUSH HOLDER
11	SPRING WASHER	36	SCREW
12	SCREW	37	CARBON BRUSH
13	BIG GEAR	38	CARBON BRUSH COVER
14	CIRCLIP	39	SCREW
15	NEEDLE BEARING HK0808	40	HANDLE ASSEMBLE
16	SCREW	41	SWITCH
17	CIRCLIP	42	VARIABLE SPEED SWITCH
18	SPRING	43	CAPACITOR
19	LOCKING PIN	44	CABLE SLEEVE
20	SCREW	45	CABLE
21	D HANDLE	46	CABLE CLAMP
22	SCREW	47	SCREW
23	GEAR BOX	49	SCREW
24	CIRCLIP	50	SCREW
25	BEARING 6000Z	51	ALLEN KEY
26	BEARING COVER		

ST20150909

