



AU-1730-01

NO.	DESCRIPTION	NO.	DESCRIPTION
1	HEX.BOLT	26	PIN
2	EXHAUST COVER	27	SET PLATE
3	SPRING WASHER	28	HEX.BOLT
4	DEFLECTOR	29	NOSE COVER A
5	SEAL WASHER	30	NOSE COVER B
6	SEAL	31	PUSHER
7	SPRING	32	MAGAZINE A
8	O-RING	33	STOP END
9	PISTON	34	CLICK LEVER PIN
10	O-RING	35	PLASTIC END COVER
11	O-RING	36	SPRING
12	DRIVE UNIT	37	SPRING
13	O-RING	38	RELEASE LATCH
14	O-RING	39	STEPPED PIN
15	COLLAR	40	MAGAZINE B
16	CYLINDER	41	HEX.BOLT
17	O-RING	42	SUPPORT
18	BUMPER	43	HEX.BOLT
19	TRIGGER VALVE SEAT	44	O-RING
20	SPRING	45	END CAP
21	TRIGGER VALVE STEM	46	AIR PLUG
22	TRIGGER VALVE HEAD	47	PLASTIC END COVER
23	BODY	48	HEX BOLT
24	JOINT GUIDE	101	SWITCH ASSEMBLY
25	TRIGGER		

RU-ST20140903

