



BC1214

NO.	DESCRIPTION
1	JUMP STARTER SOCKET
2	UP COVER
3	DOWN COVER
4	JUMP STARTER SOCKET COVER
5	BUTTON
6	BATTERY STATUS INDICATOR
7	LED
8	LED LENS
9	PCB & USB ASSEMBLY
10	Li BATTERY

RU-ST20170605

Sturm!
нас рекомендуют друзья

Sturm!
нас рекомендуют друзья