



CD3212L, CD3214L, CD3218L

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	26	THE SECOND PLANETARY GEAR
2	CHUCK	27	THE FIRST PLANETARY CARRIER
3	TORQUE ADJUSTMENT RING	28	THE FIXED GEAR RING
4	THREAD RING	29	THE FIRST PLANETARY GEAR
5	SPRING	30	WASHER
6	ADJUSTMENT BUSH	31	MOTOR GEAR
7	WASHER	32	SCREW
8	STEEL BALL	33	WASHER
9	CIRCLIP	34	MOTOR PRESS BOARD
10	WASHER	35	MOTOR
11	STEEL BALL	36	HOUSING
12	BUSH	37	TORQUE SPRING
13	SPINDLE	38	SWITCH
14	FRONT GEAR BOX	39	DIRECTION SWITCH
15	REAR GEAR BOX	40	TWO SPEED ADJUSTMENT BUTTON
16	PIN	41	SPRING
17	THE THIRD PLANETARY CARRIER	42	LED
18	GEAR RING	43	DECORATION HOUSING
19	THE THIRD PLANETARY GEAR	44	SLING
20	WASHER	45	SCREW
21	PIN	46	BATTERY PACK
22	THE SECOND PLANETARY CARRIER	47	CHARGER
23	GEAR SPEED ADJUSTMENT RING	100	GEAR BOX ASSEMBLY
24	SCREW	101	MOTOR ASSEMBLY
25	MOVING GEAR RING		

ST20140321V