



CD3218L

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	CHUCK SCREW	A31	SCREW
B2	CHUCK	A32	MOTOR COVER
A3	BIG CIRCLIP	A33	MOTOR GEAR
A4	TORQUE ADJUSTMENT PIECE	A34	MOTOR
A5	TORQUE ADJUSTMENT RING	A35	TWO SPEED CHANGE BUTTON
A6	TORQUE ADJUSTMENT NUT	A36	SPRING
A7	SPRING	A37	RIVET
A8	BIG WASHER	A39	DIRECTION CHANGLE LEVEL
A9	PIN	A40	SWITCH
A10	STEEL BALL	A41	BATTERY CONNECTION FOOT
B11	SPINDLE	A42	SLING
A12	BEARING 689Z	A44	SCREW
A13	TORQUE ADJUSTMENT SPRING	C45	BATTERY PACK
A14	GEAR BOX	C46	CHARGER
A15	TWO SPEED CHANGE SPRING	47	SPINDLE LOCK RING
A16	GEAR BOX PIN	48	SPINDLE LOCK PIN
A17	CRICLIP	49	SPINDLE LOCK BLOCK
A18	WASHER	A50	O RING
A19	INNER GEAR RING	51	HOUSING COVER
A20	THE THIRD PLANET CARRIER	52	SPRING
A21	THE THIRD PLANET GEAR	53	LED COVER
A22	WASHER	54	SCREW BITS HOLDER
A23	THE SECOND PLANET CARRIER	55	SCREW BITS
A24	THE SECOND PLANET GEAR	56	BUCKLE
A25	MOVING GEAR RING	57	SCREW
A26	GEAR BOX BUSH	58	NUT
A27	UPPER GEAR RING	59	RUBBER PIN
A28	THE FIRST PLANET CARRIER	B100	GEAR BOX ASSEMBLY
A29	THE FIRST PLANET GEAR	A101	MOTOR ASSEMBLY
A30	WASHER	C888	HOUSING ASSEMBLY