



**CD3212L CD3214L
CD3218L CD3220L CD3224L**

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	CHUCK SCREW	A27	UPPER GEAR RING
B2	CHUCK	A28	THE FIRST PLANET CARRIER
A3	BIG CIRCLIP	A29	THE FIRST PLANET GEAR
A4	TORQUE ADJUSTMENT PIECE	A30	WASHER
A5	TORQUE ADJUSTMENT RING	A31	SCREW
A6	TORQUE ADJUSTMENT NUT	A32	MOTOR COVER
A7	SPRING	A33	MOTOR GEAR
A8	BIG WASHER	A34	MOTOR
A9	PIN	A35	TWO SPEED CHANGE BUTTON
A10	STEEL BALL	A36	SPRING
B11	SPINDLE	A37	RIVET
A12	BEARING 689Z	A39	DIRECTION CHANGLE LEVEL
A13	TORQUE ADJUSTMENT SPRING	A40	SWITCH
A14	GEAR BOX	A41	BATTERY CONNECTION FOOT
A15	TWO SPEED CHANGE SPRING	A42	SLING
A16	GEAR BOX PIN	A44	SCREW
A17	CRICLIP	A45	BATTERY PACK
A18	WASHER	A46	CHARGER
A19	INNER GEAR RING	47	SPINDLE LOCK RING
A20	THE THIRD PLANET CARRIER	48	SPINDLE LOCK PIN
A21	THE THIRD PLANET GEAR	49	SPINDLE LOCK BLOCK
A22	WASHER	A50	O RING
A23	THE SECOND PLANET CARRIER	51	HOUSING COVER
A24	THE SECOND PLANET GEAR	B100	GEAR BOX ASSEMBLY
A25	MOVING GEAR RING	A101	MOTOR ASSEMBLY
A26	GEAR BOX BUSH	B888	HOUSING ASSEMBLY

ST-RU20180706 VER:2.3

Sturm!
нас рекомендуют друзья