



CHT1201

No	Description	No	Description
1	Screw	10	Left decorative cover
2	Right decorative cover	12	Power display cover
3	Housing	13	Screw
4	Button	14	Gearbox cover
5	Right fixing plate	15	Flat gasket
6	Spring	16	Dual gear
7	Left fixing plate	17	Big gear
8	Lawn Cutting Blade Assembly	18	Rubber plug
8-1	Screw	19	Screw
8-2	Base cover plate	20	Gear box
8-3	Cutting cam	21	Motor gear
8-4	Base guard	22	Motor
8-5	Shaft ring	23	Battery display board
8-6	Flat cushion	24	Handle
8-7	Lawn mower	26	Trigger
8-8	Cushion block	27	Trigger limit
8-9	Lawn cutter holder	28	Rotation limit
8-10	Pin	29	Microswitch
8-11	Base pad	30	Pin
8-12	Blade base	31	Battery pack
9	Hedge Blade Assembly	32	U-shaped buckle
9-1	Nut	33	Negative wire
9-2	Flat gasket	34	Positive wire
9-3	Slider	35	Switch wire
9-4	Hedge Knife	36	Magnet ring
9-5	Hedge knife holder	37	Hedge blade guard
9-6	Screw	38	Lawn cutting blade guard
9-7	Base pad		

