

CRS1201C

No	Description	No	Description
1-1	Blade	6-4	Balance part
1-2	Branch baffle	6-5	Motor
1-3	Torsion spring	6-6	Motor seat
1-4	Rivet	6-7	Motor gear
1-5	Bracket	6-8	Big gear
1-6	Bottom plate	6-9	Roller
2-1	Circlip \varnothing 20.5	6-10	Needle HK0610
2-2	Large washer	6-11	Shim
2-3	Lock sleeve	7	Guide fixing seat
2-4	Quick fit sleeve	8	Slide guide
2-5	Blade sleeve	9	Guide seat
2-6	Pin \varnothing 2.6x6.7	11	Clip
2-7	Steel ball \varnothing 5	12	Spring
2-8	Torsion spring	13	Unlock button
2-9	Indicator ring	14	Switch
2-10	Quick installation head	15	Connect board
2-11	Shaft sleeve seat	16	Battery pack
2-12	Shaft sleeve	17	Battery display board
2-13	Pipe	18	Battery display cover
2-14	Reciprocating rod	19	Housing
3	Pin \varnothing 3x25.8	20	Shaft circlip \varnothing 6
4	Torsion spring	21	Wool felt
5	Block button	22	Screw M3x10
6-1	Pin fixing seat	23	Screw ST3x14
6-2	Small gasket	24	Inductance
6-3	Pin \varnothing 4x12	25	Charger

CRS1201C-EX-RUS230619

