



CS5060MS

NO.	DESCRIPTION	NO.	DESCRIPTION
1	GUIDE RULER	45	INDICATOR LIGHT
2	DUST OUTLET ADAPTER	46	WORM WHEEL
3	DUST PIPE	47	GASKET
4	DUST PIPE ADAPTER	48	BEARING 608Z
6	LIMITED BOARD	49	LUMP
7	PIN Φ 4X28	50	SWITCH PIN
8	PIN Φ 4X10	51	SPRING
9	SCREW	52	RIVET
10	CONTROL LEVEL	53	SPRING
11	SPRING	54	ANTI-LOCKING BUTTON
12	GUARD LOCKING BUTTON	55	TRIGGER
13	GEAR	56	STATOR
14	WORM	57	LEFT BRUSH HOLDER
15	GEAR BOX PRESSURE BOARD	58	CARBON BRUSH
16	SPRING WASHER	59	UPPER TORSIONAL SPRING
17	SCREW	60	BRUSH HOLDER STAND
18	BEARING 6000Z	61	CABLE CLAMP
19	BEARING 606Z	62	SCREW
20	CIRCLIP	63	ALLEN KEY 3MM
21	GEAR BOX ASSEMBLY	64	SCREW
22	SCREW	65	DOWN TORSIONAL SPRING
23	KEY	66	RIGHT BRUSH HOLDER
24	SCREW	67	SWITCH
25	WORM WHEEL SHAFT	68	CABLE SLEEVE
26	INNER GUARD	69	CABLE
29	UPPER FLANGE	70	ALLEN KEY 5MM
30	CARBON BRUSH COVER	71	SCREW
31	SCREW	72	PIN
32	SCREW	73	DEPTH LOCKING SPANNER
33	CIRCLIP	74	DEPTH INDUCATOR
34	TORSIONAL SPRING	75	SLIPPER BLOCK
35	LOCKING BUTTON	76	PIN
36	BEARING PRESSURE BOARD	77	FIXING SCREW
37	CIRCLIP	78	SCREW
38	BEARING 627Z	79	BASE
39	GASKET	80	TORSIONAL SPRING
40	ROTOR	81	MOVING GUARD
41	BEARING 607Z	82	SPRING SHAFT
42	UPPER TRANSPARENT COVER	83	LOCKING NUT
43	DOWN TRANSPARENT COVER	888	HOUSING ASSEMBLY
44	SCREW		

ST20140320-01