FF1001 FF1201

NO.	DESCRIPTION
1	decorating plate
2	front guard
3	blade
4	screws
5	spring washer
6	motor
7	screws
8	rear guard
9	nut
10	screws
11	rear cover
12	switch box
13	screws
14	locating block
15	spring washer
16	nut
17	power cord
18	rubber washer
19	nut
20	rubber feet 1
21	rubber feet 2
22	tapping screw
23	stand
24	termind
25	cablt tie
26	cord mount
27	capacitor
28	screws
29	cord bushing
30	switch
31	locating block
32	nut
33	screws

FF1001 FF1201-ex-RUS221008