


GE190-25SP



NO	DESCRIPTION	NO	DESCRIPTION
1	CRANKCASE SUBASSEMBLY.	63	ELEMENT, AIR CLEANER
2	BOLT, DRAIN PLUG	64	COVER, AIR CLEANER
3	WASHERDRAIN BOLT	65	Bolt, COVER, AIR CLEANER
4	SENSOR, ENGINE OIL	67	WIND GUIDE, TOP
5	FLG.BOLTM6X15	68	SPRING,GOVERNOR
6	BOLT,DRAIN PLUG	69	SPRING, THROTTLE VALVE RETURNING
7	Locatmg Pms	70	ROD, GOVERNOR
8	Bearmg	71	ARM, GOVERNOR
9	Connect Rod Screw	72	BOLT,GOVERNOR ARM
10	CAMSHAFT ASSY.	73	PIN, SHAFT
11	CRANKSHAFT	74	SEAL, OIL
12	ROD,CONNECTING(II)	75	Rocker shim
13	BEARING	76	SHAFT, GOVERNOR ARM
14	GASKET, CRANKCASE	77	IGNITION COIL
15	OIL DIPSTICK ASSY	78	FLG.BOLT M6X29
16	COVERCRANKCASE	79	Wire clip
17	SEAL, OIL	80	FAN COVER COMP
18	FLG.BOLTM8X40	81	NUT, shaft
19	ROD, CONNECTING(I)	82	PULLEY,STARTER
20	CLIP, PISTON PIN	83	SHEATH,WIRE
21	PIN, PISTON	84	COOLING FAN
22	PISTON	85	FLYWHEEL COMP
23	FLG.BOLT M6X12	86	GRIP,STARTER
24	AIR GUIDE LOWER	87	FLG.BOLT M6X8
25	RING SET, OIL	88	CASE COMP.,RECOIL STARTER
26	RING, THE SECOND	89	SPRING,STARTER RETURN
27	RING, THE FIRST	90	CORD
28	GASKET, CYLINDER HEAD COVER	91	PULLEY,RECOIL STARTER
29	COVER SUBASSEMBLY, CYLINDER HEAD	92	SPRING,PATCHET
30	BOLT	93	PATCHET,STARTER
31	Exhaust valves stud bolt	94	PAWL GUIDE
32	BREATHER TUBE	95	CLIP SPRG.,PAWL GUIDE
33	FLG. BOLT M10X80	96	SCREW,PAWL GUIDE
34	ROTATOR, VALVE	97	BUSHING, GOVORNER C@AR
35	NUT, VALVE LOCK	98	CLIP, GOVORNER GEAR
36	NUT VALVE ADJUSTING	99	GEAR, GOVERNOR
37	ROCKER, VALVE	100	INNER WASHER,GEAR
38	SPARKPLUG	101	GOV.,CEAR SHAFT
39	RETAINER, INTAKE VALVE	102	GSKT.,EXT.
40	RETAINER, EXHAUST VALVE	103	Lock WASHER
41	SPRING,VALVE	104	Recoil Starter Set
42	BOLT, VALVE ADJUSTING	105	Governing Gear Set
43	OIL SEAL,VALVE	106	Air Cleaner Set
44	RETAINER, VALVE	107	Carburetor Set
45	PLATE SUBASSEMBLY, LIFTER STOPPER	108	Piston Rings Set
46	HEAD SUBASSEMBLY, CYLINDER	109	Gasket Set
47	VALVE,IN.TAKE	110	Muffler assembly
48	VALVE, EXHAUST	111	Heat sheld cover fixing screw
49	PUSH ROD	112	Muffler fixing nut
50	TAPPET, VALVE	113	Gasket
51	Locating Pins(φ12x20)	114	Muffler fixing nut
52	GASKET, CYLINDER HEAD	115	Fuel cap
53	AIR cleaner holder	116	Fuel cap rubber seal
54	NUT M6	117	Fuel filter
55	STUD, INTAKE	118	Fuel tank
56	GSKT.,INSULATOR	119	Fuel tank fixing tank screw
57	PLATE, CARBURETOR INSULATOR	120	Fuel tank fixing tank screw
58	GASKET, CARBURETOR	121	Rubber seal
59	CARBURETOR	122	Fuel filter
60	GASKET, AIR CLEANER	123	Clip
61	ELBOW, AIR CLEANER	124	Fuel tube
62	NUT M6	125	Clip