



HCS51185

NO.	DESCRIPTION	SPEC.	NO.	DESCRIPTION	SPEC.
1	BEARING BUSH		39	BRUSH HOLDER	
2	BEARING	607 RS	40	BRUSH HOUSING	
3	ROTOR		41	CARBON BRUSH	
4	BEARING	6000 RS	42	SCREW	M5*30
5	BEARING WRENCH		43	SCREW	M5*40
6	SPRING		44	WASHER	5
7	ALUMINIUM HOUSING		45	SPRING WASHER	
8	OIL BEARING		46	HOUSING	
9	GEAR		47	STATOR	
10	SPRING		48	PROTECTION RING	
11	LIFTING BOLT		49	CROSS TAPPING SCREW	ST4.1*80
12	CROSS TAPPING SCREW	M4*12	50	CROSS TAPPING SCREW	ST4.1*16
13	GEAR CASE COVER		51	KNOB	
14	CIRCLIP		52	CROSS TAPPING SCREW	ST4.1*16
15	CROSS TAPPING SCREW	M6*12	53	LEFT HANDLE	
16	SAFETY COVER		54	CAPACITANCE	
17	WRENCH		55	SWITCH	
18	SCREW	M4X6	56	CROSS TAPPING SCREW	ST4.1*16
19	BEARING PRESS BOARD		57	WIRE STRAIN PLATE	
20	CROSS TAPPING SCREW	M4*10	58	CABLE SHEATH	
21	OUTPUT SHAFT		59	CABLE	
22	BEARING	6001 2Z	60	RIGHT HANDLE	
23	BLADE SEAT		61	CABLE SLEEVE	
24	BLADE		62	WASHER	6
25	ALUMINIUM COVER		63	CONTROL BRACKET	
26	SCREW	M4X16	64	ALUMINUM BASE	
27	SAW BLADE COVER PLATE		65	BOLT	
28	WASHER	8	66	KNOB	
29	HEX SCREW	M8X16	67	NUT	M6
30	ADDITIONAL HANDLE COVER		68	KNOB	
31	ADDITIONAL HANDLE		69	KNOB	
32	CROSS TAPPING SCREW	ST4.1*16	70	WASHER	6
33	WASHER	4	71	BRACKET	
34	CROSS TAPPING SCREW	ST4.1*13	72	BOLT	M6X20
35	CROSS TAPPING SCREW	ST4.1*16	73	FLAT HEAD HOLLOW RIVET	Φ 6 X16
36	REAR COVER		74	DEPTH STOP	
37	CROSS TAPPING SCREW	ST4.1*13	75	DUST TUBE	
38	CLAMP		76	ALLEN KEY	6MM

HCS51185 -EX-RUI20200805