

HGC2218

NO.	DISCRIPTION	NO.	DISCRIPTION	NO.	DISCRIPTION
1	NUT M5	33	DAMPER CAP		
2	SPACER	34	ST4.8x16 SCREW	66	Paper Air Filter
3	M5x12 SCREW	35	SPRING SET	67	Plate
4	MUFFLER	36	SPRING	69	CAP
5	MUFFLER GASKET (5401)	37	CIRCLIP	70	DAMPER
6	SCREWM5x87	38	SPONGE	71	DUST SHIELD
7	M5x22 SCREW	39	BREATHER	72	Ø35SNAP RING
8	CYLINDERØ45.2	40	WEDGE BRACKET	73	OIL SEAL(L) Ø15xØ35x4.5
9	SPARK PLUG (L7T)	41	WEDGE	74	PLATE
10	INTAKE GASKET	42	CLUTCH SPRING	75	L-H GUIDE
11	INLET PIPE ASS'Y	43	WEDGE BRACKET WASHER	76	LOCATING PINØ6x9
12	INLET PIPE GUIDEØ16	44	K12x15x15 NEEDLE BEARING	77	CRANKCASE GASKET
13	CYLINDER GASKET	45	CLUTCH DRUM	78	Ø5.7CLIP
14	CIRCLIP	46	SPROCKET 3/8-7	79	VACUUM TUBE
15	PISTION PINØ11x35	47	OIL PUMP WORM	80	TUBE JOINTS
16	WASHERØ18x3.1	48	M4x10 SCREW	81	CRANKCASE (L)
17	PISTION RINGØ45.2	49	OIL PUMP COVER	82	SPARK PLUG COVER
18	PISTION Ø45.2	50	OIL SEAL (R) Ø15x28x5	83	IGNITION ASS'Y
19	K11x15x12.5 NEEDLE BEARING	51	BALL BEARING (6202)	84	CORD
20	CRANKSHAFT COMP.	52	CHOKE ROD DAMPER	85	M5x20 SCREW
21	3.0x3.7x10 WOODRUFF KEY	53	CRANKCASE (R)	86	OIL TANK CAP GASKET
22	M4x15 SCREW	54	CUSHION	87	OIL TANK CAP ASS'Y
23	OIL PUMP PIPE (0)	55	CHOKE KNOB	88	M5x25 SCREW
24	OIL PUMP	56	UNDER MAT	89	NUT
25	SEALED SPONGE	57	M5x14 SCREW	90	OIL TANK CAP ASS'Y
26	OIL PUMP PIPE (1)	58	CARBURETOR BRACKET	91	FLYWHEEL ASS'Y
27	OIL FILTER	59	SPACER	92	SHOULDER SCREW
28	M4x6 SCREW	60	ASBESTOS MAT	93	PAWL
29	OIL GUIDE PLATE	61	CARBURETOR (WT-1025) (5800)	94	SPRING
30	CHAIN GUIDE	62	M5x50 SCREW	95	LOCKNUT
31	M8x26 STUD	63	MANIFOLD COMP	96	VACUUM GUIDE
32	M5x14 SCREW	64	DAMPER	193	CLUTCH ASSEMBLY

HGC2218-EX-20200904

hanskonner

надежно. профессионально


[Ханс Кённер]

hanskonner

надежно. профессионально

[Ханс Кённер]

HGC2218



NO.	DISCRIPTION	NO.	DISCRIPTION	NO.	DISCRIPTION
121	THROTTLE TRIGGER	154	BRAKE SPRING COVER	182	REAR HANDLE COVER
122	THROTTLE SPRING	155	STOPPER PLATE	183	BREATHER ASS'Y
123	AIR FILTER COVER	156	ST4. 2x6. 5 SCREW	184	Ø6 CIRCLIP
124	M5x14 SCREW	157	TENSION PLATE	185	BREATHER PIPE
125	CYLINDER COVER	158	CHAIN TENSION ADJUSTER	186	SWITCH (ON/OFF)
126	GUIDE	159	SAWDUST PROTECTOR	187	WIRE
127	FRONT HANDLE COMP	160	Ø3x9 PIN	188	PIN
128	INSULATION AL FOIL	161	BRAKE BAND	189	PIN
129	FAN COVER	162	Ø4x22 PIN	190	LOCK BUTTON
130	THROTTLE ROD	163	HOOK	191	LOCK BUTTON ARM
131	WASHER	164	TORSIONAL SPRING	192	SPIKED BUMPER
135	SCREW	165	FRONT HAND GUARD	193	Clutch Assy
137	START HANDLE	166	Ø3 SNAP RING	194	LEVER ASS'Y
139	TRIGGER INTERLOCK ARM	167	STOP PIN	195	FUEL PIPE GUIDE
140	BRAKE SPRING (SUB)	168	GUIDE PIN	196	FUEL TANK CAP ASS'Y
141	BRAKE ARM	169	BRAKE LEVER ASS'Y	197	CLUTCH COVER ASS'Y
142	BRAKE SPRING (MAIN)	170	NUT M8	199	BUSH
143	GUIDE PIN SLEEVE	171	FUEL PIPE	200	WASHER
144	MAIN LEVER	172	Ø5x24 SPRING PIN	201	STOP BLOCK
145	SUB LEVER	173	FUEL FILTER ASS'Y	202	EASY STARTER COVER ASS'Y
146	TENSIONER PASSIVE BOLT	174	ST3. 9x14 SCREW	203	SPRING PLATE
147	TENSIONER PIN	175	FUEL BREATHER GASKET	204	EASY STARTER REEL
148	BRAKE SPRING	176	DAMPER	205	Stored Spring
149	Ø6xØ18x1. 5 PLATE WASHER	177	DAMPER PLUG	206	PAWL WHEEL
150	Ø4 SNAP RING	178	REAR HANDLE ASS'Y	207	STARTER ROPE Ø3x1000
151	RUBBER WASHER	179	DAMPER		
152	Ø3. 5 SNAP RING	180	FUEL TANK CAP WASHER		
153	ST4. 2x9. 5 SCREW	181	FUEL TANK CAP COMP		

HGC2218-EX-20200904

hanskonner

надежно. профессионально

[Ханс Кённер]

hanskonner

надежно. профессионально

[Ханс Кённер]