



hanskonner

HID2145P

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	KEYLESS CHUCK	A30	MOTOR FLANGE
A2	ADJUSTMENT PLATE	A31	DUST PROOF WASHER
A3	INTERNAL SCREW SLEEVE	A32	BALL BEARING 6000Z
A4	BIG SPRING	A33	STATOR
A5	BIG WASHER	A34	ROTOR
A6	OUTPUT SHAFT	A35	INSULATING BARRIER
A7	WASHER	A36	BALL BEARING 607Z
A8	BALL BEARING 6800Z	A37N	BRUSH CAP
A9	STEEL BALL Ø5	A38N	CARBON BRUSH
A10	GEAR CASE	A39N	BRUSH HOLDER
A11	BALL BEARING 6800Z	A40N	CARBON BRUSH HOLDER
A12	CIRCLIP Ø10	A41	SPEED PUSH BUTTON
A13	FIXED RING	A42	SPEED SPRING
A14	ROUND PIN	A43	ROUND PIN
A15	DRIVING DISC	A44	ADJUSTMENT PLATE SHRAPNEL
A16	LEVEL 3 PLANET CARRIER	A45	TENSION SPRING
A17	INNER GEAR RING	A46	INDUCTANCE
A18	LEVEL 3 PLANETARY GEAR	A47	DIRECTION SETTING BUTTON
A19	WASHER	A48	SWITCH
A20	LEVEL 2 PLANET CARRIER	A49	CAPACITOR
A21	HOOK	A50	CORD ANCHORAGE
A22	SPEED CHANGING BOX	A51	TAPPING SCREW ST4*14
A23	TAPPING SCREW ST3*12	A52	CABLE
A24	DYNAMIC GEAR RING	A53N	HOUSING ASSEMBLE
A25	LEVEL 2 PLANETARY GEAR	A54	TAPPING SCREW ST3*14
A26	LEVEL 1 PLANET CARRIER	A55	CHUCK SCREW
A27	LEVEL 1 PLANETARY GEAR	A100	GEAR BOX ASSEMBLY
A28	FIXED GEAR RING		
A29	CLAMP		

RU-HK20190905 V1.2