



JS4061S

NO.	DESCRIPTION	NO.	DESCRIPTION
1	TAPPING SCREW	26	RIGHT ENCLOSURE
2	LEFT ENCLOSURE	27	PCB
3	ADJUSTING SCREW	28	SWITCH
4	CONNECTING PLATE	29	BALANCE BLOCK
5	BASE PLATE	30	PIN
6	CIRCLIP	31	NEEDLE ROLLER BEARING
7	METAL PENDULUM SWITCH	32	LIFTING KNIFE PLATE
8	ROLLER SPRING	33	BEARING HOLDER
9	WASHER	34	BEARING 608Z
10	ROLLING METAL GUIDE	35	ROTOR
11	SAW HOLDER PIN	36	BRUSH HOLDER
12	SUPPORT ROLLER	37	CARBON BRUSH
13	ROLLER PIN	38	BRUSH BUSHING
14	BIG GEARING	39	BEARING 607Z
15	ROLLER	40	STATOR
16	FIXING RING	41	DUST CONNECTION
17	SPRING	42	CORD SLEEVE
18	HOLDER FOR SAW ARM	43	AC-CORD & PLUG
19	SOCKET HEAD SCREW	44	"O" TYPE RING
20	SOCKET HEAD SCREW	45	TAPPING SCREW
21	SAW HOLDER	46	CORD CLAMP
22	SAW ARM	47	RUBBER PIN
23	HOLDER FOR SAW ARM	48	CONNECTING PLATE
24	PROTECTING GUARD	49	CAPACITOR
25	PENDULUM SWITCH KNOB		

RU5102202

Sturm!
Germany

Sturm!
Germany