



MC8830

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|----------------------|-----|--------------------------|
| 1 | LEFT COVER | 26 | AIR PROOF LOCK |
| 2 | RUBBER FOOT | 27 | PRESSURE PIECE |
| 3 | CONNECTION ROD | 28 | CYLINDER COVER |
| 4 | BEARING 607 | 29 | AIR PRESSURE METER |
| 5 | ECCENTRIC WHEEL | 30 | HANDLE BRACKET |
| 6 | BRACKET | 31 | CABLE |
| 7 | BEARING 608 | 32 | CIGARETTE PLUG |
| 8 | MOTOR HOUSING | 33 | BREATHER PIPE |
| 9 | STATOR | 34 | HANDLE |
| 10 | ADJUST PIECE | 36 | NUT |
| 11 | ROTOR | 101 | CONNECTION ROD ASSEMBLY |
| 14 | BRUSH HOLDER | 102 | MOTOR HOUSING AND STATOR |
| 15 | BEARING HOLDER | B1 | SCREW |
| 17 | SWITCH BOX | B2 | SCREW |
| 18 | ON/OFF SWITCH | B3 | BOLT M4X100 |
| 19 | PISTON RING | B4 | CIRCLIP |
| 20 | PISTON PRESSURE RING | B5 | SPRING |
| 21 | AIR WASHER | B6 | CARBON BRUSH |
| 23 | CYLINDER BUSH | B7 | SCREW |
| 24 | RADIATOR | B8 | RIVET |
| 25 | "O" RING | B10 | BOLT M4X38 |

RU-ST20171117

Sturm!
нас рекомендуют друзья