

MC8835

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LEFT COVER	30	BREATHER PIPE
2	RUBBER FOOT	31	CABLE
137	CONNECTION ROD	32/	CIGARETTE PLUG
4	BEARING	33	HANDLE RUBBER PAD (left)
5	ECCENTRIC WHEEL	34	HANDLE RUBBER PAD (right)
6	BRACKET	35	QUICK CONNECTOR
7	BEARING	101	CONNECTION ROD ASSEMBLY
8	MOTOR HOUSING	102	MOTOR HOUSING AND STATOR
9	STATOR	B1	SCREW
10	ADJUST PIECE	B2	SCREW
11	ROTOR	В3	BOLT
12	BRUSH HOLDER	B4	CIRCLIP
13	CARBON BRUSH	B6	SPRING - ADVZLGM
15	BEARING HOLDER	В7	SCREW SPRING
16	ON/OFF SWITCH	B8	RIVET
17	RIGHT COVER	B10	BOLT
18	CABLE SLEEVE		
19	PISTON RING		
20	PISTON PRESSURE RING		R
21	AIR WASHER		
22	O RING		
23	CYLINDER BUSH		
24	RADIATOR		
25	AIR PROOF LOCK	$\Delta \mu$	) Y 3 b 9 M
26	HANDLE		
27	PRESSURE PIECE		
28	CYLINDER COVER		
29	AIR PRESSURE METER		

