



## OS8016

NO.	DESCRIPTION	NO.	DESCRIPTION
1	STATOR	20	SCREW
2	OILED BEARING	21	RUBBER SLEEVE
3	LINK TERMINAL	23	WASHER
4	BRUSH HOLDER	24	SPRING WASHER
5	BRUSH BUSHING	25	SCREW
6	CARBON BRUSH	26	TAPPING SCREW
7	ROTOR	27	STRAIN RELIEF
9	BEARING 627Z & BEARING CAP	28	CAPACITOR
10	BEARING HOLDER	29	SWITCH
11	ALUMINIUM FAN	30	CORD SLEEVE
12	BEARING 6001Z	31	CORD & PLUG
13	NUT	32	SPONGE PAD
14	STEEL WIRE CLAMP	33	DUST CONNECTION
15	OSCILLATING BRACKET	34	DUST CONNECTION EXPEND
16	BASE PLATE	888	HOUSING ASSEMBLE
17	SPONG PAD		

ST20101207-02