



## P1070

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW M4X16	33	RUBBER PACKING
2	CHIP COVER	34	FRONT BASE
3	KNOB	35	SCREW M5X18
4	SCALE PLATE	36	BASE
6	HOUSING	37	RUBBER PIN 4
8	NAME PLATE	38	BEARING 608
9	CORD GUARD	39	DROM
10	CORD	40	RUBBER PIN 4
11	STRAIN RELIEF	41	SCREW M4X55
12	SCREW M4X20	42	BRACKET
13	CAPACITANCE	43	SCREW M4X20
14	SWITCH	44	PULLEY 1
15	HANDLE COVER	45	BELT COVER
16	SCREW M4X25	46	RUBBER PIN 4
17	BEARING 6000	47	SCREW M4X25
20	ARMATURE	48	BELT
22	BEARING 627	49	PULLEY 2
23	STATOR	50	BEARING 6000
24	SCREW M4X16	51	RUBBER PIN 4
25	AUXILIARY BAFFLE PLATE	52	ADJUST PLATE
26	SCREW M4X10	53	SCREW M4X5
27	BEARING COVER	54	DROM PLATE
28	CARBON BRUSH	55	BOLT M6X17
29	BRUSH HOLDER CAP	56	INDUCTOR
31	SCREW M5X10	57	BRUSH HOLDER
32	COMPRESSION SPRING	58	BLADE

RU-ST20140905