

## нас рекомендуютР10,90 ям

нас

٠.				
	NO.	DESCRIPTION	NO.	DESCRIPTION
	1	COVER OF FRONT HANDLE	34	DBELT
	2	TAPPING SCREW ST4×16	35	BELT COVER
	3	FRONT HANDLE	36	TAPPING SCREW ST4×14
	4	SCALE	37	SMALL BELT WHEEL
	5	DOUBLE HEAD SPLINE	38	TAPPING SCREW ST4×12
	6	BOLT M6X10	39	BEARING COVER
	7	SPRING WASHER Ø6XØ9X2	40	BEARING 608
	8	FLAT WASHER Ø6XØ9X2	41	ROTOR
	9	SCREW ARBOR	42	BEARING 626
	10	FOAM PAD 1	43	WIND DEFENDER
	11	FOAM PAD 2	44	TAPPING SCREW ST4X55
	12	FRONT BASE BOARD	45	STATOR ADV369M
	13	BEARING 607	46	HANDLE COVER
	14	KNIFE SHAFT	47	INDUCTOR
	15	TIGHTEN BLOT	48	LABEL
	16	KNIFE SUPPORT	49	HANDLE COVER
	17	M5 BOLT	50	SWITCH
	18	KNIFE	51	CORD CLAMP BOARD
	19	KNIFE CLAMP BOARD	52	CAPACITOR
	20	DUST CONNECTION ADAPTOR	53	POWER CORD AND PLUG
	21	KNIFE GUARD	54	CORD GUARD
4	22	RETURN SPRING	55	CARBON BRUSH
	23	HOUSING	56	BRUSH HOLDER
-	24	NUT M6	57	BRUSH CLAMP
	25	REAR BASE BOARD	58	INLET COVER
1	26	HOUSING 2 H A / HOT A	60	SPANNER
	27	DEPTH GAUGE	61	DUST BAG
	28	HEATING SHRINK TUBE	62	BOLT
	29	KNOB	63	CASTLE NUT
	30	BEARING 6000	64	FIX BRACKET
ı	31	BEARING COVER	65	PARALLEL GUIDE
Ī	32	BIG BELT WHEEL		
ı	33	NUT M8		— (

нас рекомендуют друзьям