



RH25901

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	STEEL RING18*2	34-1	BUTTON	66	SCREWM5*55
2	STEEL COVER	34-2	BUTTON SET	67	BRUSH COVER
3	STEEL BALL RACK	34-3	RING	68	BRUSH HOLDER
4	SPRING30.2*3.5*76	35	SCREWM4*15	69	CARBON BRUSH
5	CYLINDER HOUSING	36	GEAR HOUSE	70	SCREWM5*8
6	OIL SEAL	37	OIL COVER	71	TENSION SPRING
7	CIRCLIP Ø35	39N	SMALL BEVEL GEAR	72	CROSS SCREWST4.8*60
8	BIG WASHER45*54.5*1	40	ADJUSTING WASHER	73	HANDLE
9	BEARING61907-RZ	41	BEARING6002-RS	74	CROSS SCREWM5*20
10	SCREWM5*22	42	WASHER14*20*0.5	75	SWITCH
11	SPRING WASHER5	43	SQUARE WASHER	76	SCREW ST3.9*18
12	PLAIN WASHER5	44	WEARING PIECE	77	SCREW ST4.8*25
13	STEEL BALL 7.14	45	BIG GEAR	78	CAPACITY
14	GUARD RING SLEEVE	46	SQUARE HOLD WASHER	79	CABLE PLATE
15	OIL SEAL	47	PLAT WASHER	80	INDUCTANCE
16	O-RING 11*2	48	SCREW NUT M10	81	CABLE SHIELD
17	SECOND STRIKER	49	BEARING 627RZ	82	CABLE
18	STEEL BALL7.94	50	CRANK	83	SQUARE-HEAD SCREWM8*35
19	CYLINDER	51	CIRCLIP 17	84	BRACKET
20	FLAT KEY	52	BEARING6003-RS	85	U BRACKET
21	PLACTIC RANGE RING	53	WASHER	86	HOOP
22	DUCT	54	COMPRESSION SPRING	87N	SIDE HANDLE
23	SPRING37*3.5*76	55	CIRCLIP35	88	BACK COVER
24N	BIG BEVEL GEAR	56	SMALL GEAR	89	SCREW ST3.9*16
25	STEEL RING28*1.6	57	SQUARE KEY5*5*21.5	90	SWITCH COVER
26	O-RING19*3.1	58	DOME PIN	91	SMALL OIL SEAL
27	RAMMER	59	MIDDLE COVER	92	HANDLE COVER
28	CIRCLIP 47	60	FAN GUIDE	93	SCREW M4*6
29	OIL BEARING30*47*7	61	BEARING6001-RS	94	O-RING 12*2
30	PISTON	62	ROTOR	95	FUNCTION CHANGE BUTTON
31	PISTON PIN	63	STATOR	96	NEEDLE BEARINGHK1210
32	CONNECTION ROD	64	BEARING608-RZ	97	STEEL BUSHING
33	NEEDLE BEARING HK0810	65	HOUSING		

RU-ST20170824-03

нас рекомендуют друзья