



SF4001

| NO. | DESCRIPTION |
|-----|------------------|
| 1 | Center Piece |
| 2 | Front Grill |
| 3 | Spinner |
| 4 | Blade |
| 5 | Plastic Nut |
| 6 | Rear Grill |
| 7 | Front Enclosure |
| 8 | Motor |
| 9 | Capacitor |
| 10 | Oscillating |
| 11 | Rear Enclosure |
| 12 | Oscillating Arm |
| 13 | Neck |
| 14 | Fan body |
| 15 | Tighten Screw |
| 16 | Power cord |
| 17 | Column |
| 18 | Column Screw |
| 19 | Cross base |
| 20 | Decorating Ends |
| 21 | Decorating Cover |
| 22 | Piano-Key |

SF4001-ex-RUS221008