



SG9612

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|----------------|------|------------------|
| 1 | NOZZLE | 17-1 | ADJUST POLE |
| 2 | LOCK NUT | 17-2 | ADJUST KNOB |
| 3 | VALVE | 18 | REGULATE KNOB |
| 4 | O-RING | 19 | SHOCK ABSORBER |
| 5 | CYLINDER | 20 | ACTIVE IRON |
| 6 | PISTON SPRING | 21 | RUBBER HEAD |
| 7 | PISTON | 23 | TRIGGER |
| 9 | SCREW | 24 | SWITCH |
| 10 | DRIVER | 25 | TERMINAL BLOCK |
| 11 | DRIVER FIXED | 26 | PUMP HOUSING |
| 12 | DRIVER HOUSING | 27 | SUCTION TUBE |
| 13 | CORD BRACKET | 28 | CONTAINER |
| 14 | CORD SLEEVE | 30 | LABEL |
| 15 | CORD & PLUG | 888N | HOUSING ASSEMBLE |
| 16 | BOARD SPRING | | |

ST20120712-02