



SG9645PR

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SWITCH BUTTON	46	VALVE
2	SWITCH	47	O-RING
7	TERMINAL	48	INLET VALVE BASE
9	AMBULACRUM	50	SPRING
10	GEAR WHEEL(SMALL)	51	INLET VALVE CAP
11	FILLING PIECE	52	INLET VALVE CONNECTOR
13	FAN	53	CLIP
14	CIRCLIP	54	INLET SCREW
15	KNOB	55	WATER INLET PIPE
16	SCREW CAP	56	PIPE CLIP
17	SPRING	57	FILTER HOLDER
18	O-RING	58	FILTER
19	CONNECTOR SHAFT	73	LENGTHEN ATTACHMENT 2
20	SPRING	74	LENGTHEN
21	DISCHARGE GROUP	75	LENGTHEN ATTACHMENT 1
22	O-RING	76	CURVE PIPE ATTACHMENT
23	DISCHARGE COMBINED COMPONENTS	77	RUBBER SEAL
24	OUTLET VALVE	78	ROLLER SUPPORT
25	SPRING	79	ROLLER
26	O-RING	80	ROLLER COVER
27	OUTLET SCREW	81	RUBBER HEAD
28	OVERFLOW HOSE	82	SEAT CUSHION
29	HANDLE ATTACHMENT	201	OPERATING HANDLE ASSEMBLY
31	CORD	30	SCREW
32	CORD SLEEVE	59	OUTLET PIPE
33	CORD ANCHORAGE	60	PIPE ATTACHMENT
34	SCREW	61	ADJUSTMENT SHAFT
35	WASHER	62	BODY AXIS
36	GEAR WHEEL(LARGE)	63	BOLT Ø3X25MM'
37	COPPER BUSH	64	ADJUST KNOB
38	SHAFT	65	STEP
39	HOUSING ASSEMBLY	66	SEAL 6.3X2
40	SCREW	67	THREE PIPT CONNECTOR
41	MOTOR	68	HANDLE HOUSING
42	DRIVE SHAFT	69	SEAL Ø10X2
43	WASHER	70	HANDLE HOUSING
44	PUMP SHEET FIXING PART	71	INTERNAL CONNECTOR
45	SCREW	72	TIGHTEN

ST20130413