



TC9811

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDE CALIPERS	30	BEARING 606
2	PINION	31	OUTSIDE CALIPERS
3	BEARING 629 NSK	32	BIG GEAR
4	KEY	33	DISTANCE BUSH
5	ARMATURE	34	INSIDE CALIPER
6	CREEPAGE CHECK RING	35	BEARING 6201
7	BEARING 608	36	FRONT COVER
8	BAFFLE PLATE	37	SPRING WASHER
9	SCREW	38	SCREW
10	STATOR	39	OIL SEAL
11	CABLE PLATE	40	KEY
12	SCREW	41	OUTPUT SHAFT
13	SWITCH COVER	42	IN-FLANGE
14	STOP-COVER	43	OUT-FLANGE
16	SWITCH	44	SOCKET SPANNER
17	CABLE	45	BOLT
18	PROTECTOR	46	OPEN SPANNER
19	HOUSING	47	SCREW
20	SCREW	48	IRON COVER
21	LABLE	49	BASE PLATE
22	TENSION SPRING	50	PIN
23	BRUSH HOLDER	51	SCREW
24	CARBON BRUSH	52	CAPACITANCE
25	BRUSH HOLDER COVER	53	INDUCTANCE
26	SCREW	55	WASHER
27	O-RING	56	TAP
28	MOTOR HOUSING	57	WATER HOSE CONNECTOR
29	PAPER WASHER	58	WATER HOSE

ST20131008