



WP97120FC

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|-----------------------------|-----|---|
| 1 | Rear cover | 29 | Connector |
| 2 | Hole pipe | 30 | O-ring |
| 3 | Stator | 31 | Stainless steel gasket |
| 4 | Connecting nut | 32 | Rotor |
| 5 | Three - way valve body | 33 | Porcelain shaft |
| 6 | Knob | 34 | Impeller cover |
| 7 | O-ring | 35 | Axle cap |
| 8 | Seal gasket | 36 | O-ring |
| 9 | Valve spool | 37 | Plastic filter |
| 10 | Compactly rotating parts | 38 | Filter cover |
| 11 | O-ring | 39 | Tapping screw |
| 12 | Outer tube | 40 | Ring gasket of impeller cover |
| 13 | Inside tube | 41 | Gasket |
| 14 | Sprinkler head sleeve A | 42 | Block ring |
| 15 | Sprinkler head sleeve | 43 | Base plate |
| 16 | O-ring | 44 | Sucker |
| 17 | Spray head body | 45 | Main pump housing |
| 18 | Sprinkler head core | 46 | Scaleboard |
| 19 | Spring | 47 | Left lining plate |
| 20 | Sprinkler cap | 48 | Right lining plate |
| 21 | Spray head body | 49 | Cable sheath |
| 22 | Sprinkler head | 50 | Power cord |
| 23 | Spray head body | 51 | Aluminum shell |
| 24 | Sprinkler head core | 52 | Gasket |
| 25 | Sprinkler head core cover | 53 | Grounding lug |
| 26 | Sprinkler head upper sleeve | 54 | Screw |
| 27 | Sprinkler head lower sleeve | 55 | Spring washer |
| 28 | Connector | 101 | Main pump housing assembly (2+3+45+46+...55) |

WP97120FC-EX-20211028