

WP9790P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	POWER CABLE	29	"O" RING
2	THREAD COVER	30	CAPACITOR COVER
3	COPPER COVER	31	CAPACITOR
4	CABLE JACKET	32	SCREW
5	NUT	33	SPRING WASHER
6	"O" RING	34	WASHER
7	FLOAT SWITCH	35	"O" RING
8	SCREW	36	"O" RING
9	FLOAT SWITCH LOCK	37	SEAL WASHER
10	RUBBER SLEEVE	38	DOWN BEARING HOLDER
11	SCREW	39	SPRING WASHER
12	WASHER	40	NUT
13	SCREW	41	MECHANICAL SEAL
14	BODY	42	RUBBER WASHER
15	SCREW	43	SCREW
16	SCREW	44	"O" RING
17	SPRING WASHER	45	"O" RING
18	WASHER	46	SCREW
19	RUBBER SLEEVE	47	COVER
20	UPPER BEARING HOLDER	48	SCREW
21	WAVE SPRING WASHER	49	SKELETON SEAL
22	BEARING	50	WASHER
23	ROTOR	51	VANE
24	STATOR	52	WASHER
25	COLDER SLEEVE	53	SPRING WASHER
26	PIPE CONNECTION	54	NUT
27	"O" RING	55	TURBINE HOUSING
28	BEND PIECE	56	MESH COVER

RU5110701

