



ДШ-12Л, ДШ-14Л, ДШ-18Л

NO.	DESCRIPTION	NO.	DESCRIPTION
B1	CHUCK SCREW	B27	the first planet gear
B2	CHUCK	B28	the first planet gear ring
B3	TORQUE ADJUSTMENT RING	B29	motor gear
B4	TORQUE ADJUSTMENT NUT	B30	press board
B5	SPRING	B31	screw
B6	WASHER	B32	motor press board
B7	SPINDLE	33	motor
B8	BEARING 688Z	B34	internal cable
B9	STEEL BALL	B35	switch
B10	PIN	B36	direction switch
B11	GEAR BOX	B37	buckle
B12	BEARING 688Z	B38	screw
B13	CIRCLIP	B39	screw bits holder
B14	THE THIRD PLANETARY GEAR CARRIER	B40	screw bits
B15	GEAR RING	B41	spring
B16	WASHER	B42	decoration cover
B17	THE THIRD PLANETARY GEAR	B43	housing
B18	THE SECOND PLANETARY GEAR CARRIER	B44	screw
B19	THE SECOND PLANETARY GEAR	B45	rope
B20	TWO SPEED CHANGE GEAR RING	B46	magnet (only for ДШ-18Л, ДШ-14Л)
B21	PLASTIC GEAR RING	B47	battery pack
B22	SCREW	48	charger
B23	shrapnel for two speed change button	888B	gear box assembly
B24	two speed change button		
B25	spring for two speed change button		
B26	the first planet carrier		

RU-EN20190527 VER1.3