




ДШС-12П1 ДШС-12-1L ДШС-14-1L



NO.	DESCRIPTION	NO.	DESCRIPTION
1	LEFT SCREW M5x20	25	BACK GEAR BOX
2	KEYLESS CHUCK	26	THE SECOND GEAR RING
3	RING ϕ 20.4	27	THE FIRST PLANET CARRIER
4	PRESS BOARD	28	THE FIRST PLANET GEAR
5	TORQUE RING	29	THE FIRST GEAR RING
6	BIG NUT	30	LOCATING WASHER
7	SPRING	31	GEARBOX COVER
8	TORQUE SPRING	32	MOTOR STATOR
9	SPINDLE	33	MOTOR ROTOR
10	BEARING 689Z	34	TWO SPEED CHANGE BUTTON
11	TWO SPEED CHANGE SPRING	35	GEAR POSITION WASHER
12	FRONT GEAR BOX	36	WIRE SPRING
13	SPING	37	RIVET
14	GEARBOX PIN	38	SCREW ST2.9x14
15	RING ϕ 9	39	HOUSING
16	SMALL WASHER	40	BRUSHLESS MOTOR CONTROLLER
17	PIN	41	DIRECTION LEVER
18	STEEL BALL ϕ 4	42	SWITCH
19	THE THIRD PLANET CARRIER	43	CONNECTION BOARD
20	THE THIRD PLANET GEAR	44	BATTERY PACK
21	INNER GEAR RING	45	U BUCKLE
22	BIG WASHER	46	CHARGER
23	THE SECOND PLANET CARRIER	100	GEAR BOX ASSEMBLY
24	THE SECOND PLANET GEAR		

ДШС-12П1 ДШС-12-1L ДШС-14-1L-EX-RUS20210918

