



## ДШС-3312Л, ДШС-3314Л, ДШС-3318Л

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	25	THE FIRST PLANETARY GEAR CARRIE
2A	CHUCK	26	THE FIRST PLANETARY GEAR
3	TORQUE ADJUSTMENT RING	27	INNER GEAR RING
4	TORQUE ADJUSTMENT NUT	28	MOTOR GEAR
5	SPRING	29	WASHER
6	WASHER	30	SCREW
7A	SPINDLE	31	MOTOR PRESS BOARD
8	BEARING 688Z	32	MOTOR
9	STEEL BALL	33	INTERNAL CABLE
10	PIN	34	LED PCB
11	GEAR BOX	35	TORQUE SPRING
12	BEARING 688Z	36	DIRECTION LEVER
13	CIRCLIP	37	SWITCH
14A	THE THIRD PLANET BRACKET	38	HOUSING
15	GEAR RING	39	SCREW
16	WASHER	40	STRAP
17	THE THIRD PLANETARY GEAR	41	BATTERY PACK
18	THE SECOND PLANETARY GEAR CARRIER	42	CHARGER
19	THE SECOND PLANETARY GEAR	43	LOCK RING
20	TWO SPEED CHANGE GEAR RING	44	LOCK PIN
21	PLASTIC GEAR RING	45	TRIANGLE BLOCK
22	SCREW	888A	GEAR BOX ASSEMBLY
23	TWO SPEED CHANGE BUTTON	889	MOTOR ASSEMBLY
24	SPRING		

RU-SO20171222-02  
VER:1.2