




ПЕС-25101

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	DUST CUP	A51	SPRING
A2	SPRING RING	A52	NEEDLE BEARING HK0609
A3	LOCKING SLEEVE	A53	GEAR
A4	WASHER OF DUST CUP	A54	BEARING K15
A5	STEEL BALL	A55	AWAY-POLED BEARING
A6	WASHER	A56	NEEDLE BEARING HK0908
A7	TOWER-SHAPED SPRING	A57	"CIRCLIP "
A8	SELF-TAPPING SCREW	A58	FORK
A9	GEAR BOX	A59	BEARING 699Z
A10	OIL SEAL	A60	MID-SHAFT
A11	PULL-THUST SET	A61	BEARING 609Z
A12	NEEDLE BEARINGHK0709	A62	ROTOR
A13	WASHER	A63	BEARING 607Z
A14	SELF-TAPPING SCREW	A64	WIND GUIDE
A15	SPRING RING	A65	SELF-TAPPING SCREW
A16	SLEEVE WASHER	A66	STATOR
A17	SLEEVE SPRING	A67	BEARING BUSH
A18	BIG GEAR	A68	LABEL 1
A19	O-RING	A69	HOUSING
A20	IRON CORE	A70	LABEL 2
A21	KNOB	A71	LABEL 3
A22	SPRING	A72	BRUSH HOLDER
A23	LOCKING KNOB	A73	CARBON BRUSH
A24	DRILLCOVER	A74	SELF-TAPPING SCREW
A25	"CIRCLIP "	A75	HOUSING COVER
A26	DRILL COVER CONNECTOR	A76	SELF-TAPPING SCREW
A27	PISTON KEY	A77	SELF-TAPPING SCREW
A28	POSITION-LIMITED RING	A78	SWITCH
A29	"CIRCLIP "	A79	INSULATION PIECE
A30	OIL SEAL	A80	BEARING WASHER
A31	POSITION-LIMITED SLEEVE OF SPINDLE	A81	SELF-TAPPING SCREW
A32	HAMMER SPINDLE	A82	CABLE
A33	SPINDLE SETS	A83	CABLE SLEEVE
A34	O-RING	A84	CABLE CLAMP
A35	O-RING	A85	HANDLE RING
A36	LIMITED COVER	A86	SCREW
A37	PISTON	A87	KNOB
A38	O-RING	A88	HANDLE COVER
A39	CYLINDER	A89	RULER BOX
A40	WASHER	A90	NUTM6
A41	PIN	A91	NUT M8
A42	BRACKET SLEEVE	A92	HANDLE
A43	O-RING	A93	RULER
A44	BRACKET SUPPORT	A94	BRUSH HOLER SPRING
A45	BRACKET	A100	INTERNAL CABLE 1
A46	O-RING	A102	INTERNAL CABLE 2
A47	COVER	A103	INTERNAL CABLE 3
A48	RUBBER WASHER	A104	CHANGE KNOB ASSI
A49	CAM WASHER	A105	AUXILIARY HANDLE
A50	SPRING SUPPORT	A106	BIT HOLDER ASS