



TBC-3022K

NO.	DESCRIPTION
A1	FRONT GRILL
A2	FRONT PTC BRACKET
A3	PTC
A4	THERMAL CUT-OUT
A5	BACK PTC BRACKET
A6	SWITCH
A7	THERMOSTAT
A8	POWER INDICATOR
A9	KNOB
A10	LOCK
A11	CONTROL BOX
A12	SCREWS
A13	GASKET
A14	THE BLADES CLAMP
A15	FAN BLADE
A16	FAN BASE
A17	MOTOR
A18	MOTOR SUPPORT
A19	BACK GRILL
A20	OUTER CASING
A21	CABLE&PLUG
A22	SCREW
A23	BOTTOM FRAME

RU-SO20180412 VER:2.1