



ТПС-2027 ТПС-3027

| NO. | DESCRIPTION |
|-----|---------------------|
| 1 | FRONT GRILL |
| 2 | HEATING ELEMENT |
| 3 | KNOB |
| 4 | SEALING RING |
| 5 | CONTROL BOX |
| 6 | SWITCH |
| 7 | RE-SET THERMOSTAT |
| 8 | BI-METAL THERMOSTAT |
| 9 | PROTECTIVE RING |
| 10 | INNER CASING |
| 11 | OUTER CASING |
| 12 | POWER CORD LOCK |
| 13 | POWER CORD |
| 14 | SCREWS |
| 15 | BACK GRILL |
| 16 | MOTOR |
| 17 | FAN BASE |
| 18 | FAN |
| 19 | THE BLADES CLAMP |
| 20 | GASKET |
| 21 | SCREWS |
| 22 | SCREWS |
| 23 | UPPER HALF HANDLE |
| 24 | UNDER HALF HANDLE |
| 25 | METAL HANDLE |
| 26 | FIXED SCREWS |

RU-SO20150610