



## УШМ1-150Р

NO.	DESCRIPTION	NO.	DESCRIPTION
1	DOWN FLANGE	25	BEARING 608Z
2	GRINDING WHEEL	26	BEARING BUSH
3	UPPER FLANGE	27	WIND GUIDE
4	GUARD	28	SCREW ST3.9X65
5	SPINDLE	29	STATOR
6	ANTI-DUST COVER	30	HOUSING
7	SCREW M4X14	31	RIGHT BRUSH COVER
8	FRONT COVER	32	SCREW ST2.9X10
9	BEARING 6201Z	33	CARBON BRUSH
10	CIRCLIP 32	34	COIL SPRING
11	GEAR	35	BRUSH HOLDER
12	NEEDLE BEARING HK0810	36	LEFT BRUSH COVER
13	CIRCLIP 6.2	37	SCREW ST4.2X16
14	SCREW ST4.2X22	38	REAR HANDLE
15	SPRING	39	VARIABLE SPEED SWITCH
16	LOCKING PIN	40	SWITCH
17	GEAR BOX	41	CAPACITOR
18	NUT M6	43	SCREW ST4.2X14
19	PINION	44	CABLE CLAMP
20	BEARING 629Z	45	CABLE SLEEVE
21	PRESS BOARD	46	CABLE
22	SCREW M4X12	47	SIDE HANDLE
23	ROTOR	48	SPANNER
24	ANTI-DUST WASHER		

USM1-150R-EX-RUS230213