



NO.	DESCRIPTION MHHOBALLM	NO.	DESCRIPTION
1	SOFT HANDLE COVER	38	MOVING GUARD
2	HANDLE	39	BEARING 6001
3	CORD & PLUG	40	OUTPUT SHAFT
4	CORD SLEEVE	41	WOODRUFF KEY
5	SCREW	42	BEARING COVER
6	CORD ANCHORAGE	43	SCREW
7	CAPACITOR	44	INNER FLANGE
8	SWITCH	45	SAW BLADE
10	REAR COVER	46	OUTER FLANGE
11	DECORATED BOARD	47	PLAIN WASHER
12	CARBON BRUSH	48	HEX SCREW
13	BRUSH COPPER NEST	49	PULLING SPRING
14	BRUSH HOLDER	50	SCREW
15	SCREW	51	SCREWIННОВАЦИИ POCCI
16	SPRING WASHER	52	SCREW
17	HOUSING	53	RUBBER BLOCK
18	ELECTRIC CONNECT PIECE	54	CONNECTION SCREW
20	STATOR	55	KNOB FOR ANGLE ADJUSTMENT (I)
21	SCREW	56	DEPTH STAND
22	WIND GUARD	57	SCREW
23	BEARING 608	58	BASE PLATE
24	ROTOR	59	RIVET
25	BEARING 6000	60	SCREW FOR FIXED PARALLEL GUIDE
27	CENTRAL SUPPORTER	61	ANGLE STAND
28	OILED BEARING	62	KNOB FOR ANGLE ADJUSTMENT (II)
29	CIRCLIP	63	SCREW
30	BIG GEAR	64	COVER
31	BEARING BASE MHHORALIM	65	TAPPING SCREW
32	SPRING WASHER	66	WASHER
33	SCREW	67	LOCK SCREW
34	LOCK NUT	68	MOVING GUARD KNOB
35	FIXED GUARD	69	SCREW
36	CRICLIP	70	ANGLE STAND
	DEPTH LOCK BUTTON	71	SCREW

RU-SO20160914

