



ЦПС-50200

NO.	DESCRIPTION	NO.	DESCRIPTION
A2	SCREW	A39	MOVING GUARD
A3	SCREW	A40	WASHER
A4	CORD&PLUG	A41	CIRCLIP
A5	SCREW	A42	BLADE
A6	CORD SLEEVE	A43	BEARING 6201
A7	SWITCH	A44	CIRCLIP
A8	CAPACITOR	A45	MIDDLE COVER
A9	SCREW	A47	HEX BOLT
A10	CABLE CLAMP	A48	WASHER
A11	SCREW	A49	OUTER FLANGE
A12	COVER	A50	INNER FLANGE
A13	BEARING CLAMP	A51	PULL SPRING
A14	ROTOR	A52	SCREW
A15	BEARING 6200	A54	FORE COVER
A17	WIND GUARD	A55	HEX NUT
A18	STATOR	A56	RIVING KNIFE
A19	HOUSING	A57	TOP HANDLE
A20	TWIST SPRING	A58	DOWN HANDLE
A21	FLAT WASHER	A59	HEX BOLT
A22	CIRCLIP	A60	ANGLE ADJUSTMENT BRACKET
A23	BRUSH HOLDER	A61	RIGHT BRACKET
A24	CARBON BRUSH	A62	RETAINING RING
A25	SCREW	A63	HEX SCREW
A26	SCREW	A64	DEPTH ADJUSTMENT BRACKET
A27	REAR COVER	A65	LONG WING BOLT
A28	SCREW	A66	WING BOLT
A29	OIL STORAGE RING	A67	LEFT BRACKET
A30	GEAR BOX	A68	RIVET
A31	BEARING 629	A69	BASE PLATE ASSEMBLY
A32	BIG GEAR	A70	CONNECTION PIN
A33	OUTPUT SHAFT	A71	TWIST WASHER
A34	BEARING 6204	A72	SCREW
A35	CIRCLIP	A73	WASHER
A36	SCREW	A74	WING NUT
A37	FIXED GUARD	A888	HANDLE ASSEMBLY
A38	SCREW		

RU-SO20160722
VER:2.1

