


ЭТ-2500Р



ЭТ-2500Р

NO.	DESCRIPTION	NO.	DESCRIPTION
1	gearbox assy	38	press spring2
1.01	screw M10X1.25Left	39	line board
1.02	up press plate	40	screw ST4.2X16
1.03	down press plate	41	trigger
2	blade	42	press spring3
3	screw M5X12	43	switch
4	screw M6X25	44	right handle
5	line cover	45	screw ST4X16
6	2.0 line	46	screw M5X30
7	line seat	47	connector line
8	ring 12	48	soft shaftB 642
9	press spring	49	steel tubeB
10	line housing	50	ring 32
11	bush	51	bearing 6201
12	shaft1	52	gear shaft
13	grass board base	53	bearing HK1010
14	knife	54	front surport
15	screwST4X16	55	screwST4.8X16
16	grass board	56	bearing 6900
17	guard plate	57	rotor
18	screw M6X22	58	bearing607
19	rivet4x6	59	stator
20	steel tubeA 760	60	carbon brush
21	soft tubeA 784	61	copper sleeve
22	connector	62	carbon brush surport
23	button	63	rubber plate
24	screwM4X10	64	rubber plate2
25	screwM6X14	65	screwM5X14
26	rubber sleeve	66	housing
27	tubeA	67	left edge
28	screwM5X30	68	connector seat
29	handle fixing seat1	69	right edge
30	screwM5w	71	power cord
31	handle fixing seat2	72	sheath
32	handle fixing seat3	73	buckle
33	tube sleeve	74	torion spring
34	tubeB	75	belt
35	screwM5B	76	button1
36	left handle	77	button bar
37	pole		