




AC9323

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	BOLT M6X55	A39	FAN COVER
A2	CYLINDER HEAD	A40	TEE CONNECTOR
A3	AIR FILTER	A41	NUT 3/4-16
A4	CYLINDER HEAD GASKET	A42	RADIATOR TUBE ASSY
A5	VALVE PLATE	A43	RIGHT-ANGLE CONNECTOR
A6	ALUM GASKET	A44	SCREW M4X10
A7	VALVE CLACK	A45	SPRING WASHER $\Phi 4$
A8	VALVE PLATE GASKET	A46	CAPACITY COVER
A9	PISTON RING	A47	CAPACITY
A10	PISTON OIL RING	A48	CIRCUIT BREAKER
A11	PISTON	A49	POWER CODE
A12	CIRCLIP	A50	PRESSURE SWITCH
A13	PISTON PIN	A51	TANK PRESSURE GAUGE
A14	BOLT M8X25	A52	SAFETY VALVE
A15	SPRING WASHER $\Phi 8$	A53	BALL VALVE
A16	CYLINDER	A54	OUTLET VALVE
A17	CYLINDER GASKET	A55	REGULATOR
A18	BREATH PIPE	A56B	DISCHARGE PIPE
A19	OIL LEVELER	A57B	RELEASE PIPE
A20	OIL LEVELER GASKET	A58B	NUT M10X1
A21	BOLT M6X10	A59	ELBOW CONNECTOR
A22	CRANK CASE COVER	A60	CHECK VALVE
A23	RUBBER GASKET	A62B	AIR TANK
A24	CONNECTING ROD	A63B	NUT M5
A25	CRANK	A64B	DRAIN COCK
A26	BOLT M8X35	A65B	RUBBER FOOT
A27	CRANK CASE	A66B	BOLT M5x20
A28	BOLT M5X20	A67B	BOLT M10x46
A29	SPRING WASHER $\Phi 5$	A68B	WHEEL
A30	SEALING RING	A69B	BUSH $\Phi 10$
A31	BEARING 6205	A70B	WASHER 10
A32	ROTOR	A71B	SPRING WASHER 10
A33	STATOR	A72B	NUT M10
A34	MOTOR SHELL	A73B	BOLT M8x20
A35	MOTOR COVER	A74B	NUT M8
A36	FAN COVER SEAT		
A37	FAN		
A38	CIRCLIP		

RU-ST20160616
VER:2.1