



AG9012BE[®]

NO	DESCRIPTION	NO	DESCRIPTION
1	SPANNER	27	SCREW M4X10
2	UPPER FLANGE	28	FLAT GASKET 8
3	INNER FLANGE	29	ROTOR
4	WHEEL GUARD	30	BEARING 607
5	DUST COVER	31	AUXILIARY HANDLE
6	OUTPUT SHAFT	32	SCREW ST3X10
7	SCREW M4X14	33	WIND SHIELD
8	FRONT COVER	34	STATOR
9	O-RING	35	DUST SEAL
10	BEARING 6201	36	HOUSING
11	CIRCLIP $\Phi 32$	37	CONTROLLER ASSEMBLY
12	BIG GEAR	38	INSERT SPRING 2.8
13	NEEDLE HK0810	39	HEAT TUBE $\Phi 4$
14	SELF-LOCKING PIN	40	CABLE PRESSURE PLATE
15	O-RING	41	SCREW ST4X12
16	SCREW ST4X20	42	CABLE SHEATH
17	HEAD SHELL	43	SWITCH BUTTON
18	SELF-LOCKING SPRING	44	PULL ROD
19	SELF-LOCKING CAP	45	RETURN SPRING
20	FELT PLUG	46	BACK COVER
21	HEX. NUT M6	47	RIGHT DUST PLATE
22	SMALL GEAR	48	HEAT TUBE $\Phi 4$
23	FLAT GASKET 7	49	LEFT DUST PLATE
24	O-RING	50	SCREW ST3.5X100
25	BEARING 608	51	CABLE
26	PRESSURE PLATE	52	SCRIBER

нас рекомендуют друзья

нас рекомендуют друзья AG9012BE-EX-RU240311-1