




AG9012TL

NO.	DESCRIPTION	NO.	DESCRIPTION
A1N	WHEEL GUARD	A27	ARMATURE
A2	OUTER FLANGE	A28	BAFFLE PLATE
A3	INNER FLANGE	A29	INSULATION WASHER
A4	SPINDLE	A30	BALL BEARING 607-2Z
A5	WOODRUFF KEY	A31	BEARING BUSH
A6	DUSTPROOF RING	A32	ST SCREW ST4*70
A7	SCREW M4*14	A33	STATOR
A8	SPRING WASHER	A34	BUTTON
A9	FLAT WASHER	A35	NAMEPLATE
A10	BALL BEARING 6201-2RS	A36	MOTOR HOUSING
A11	FRONT COVER	A37	CARBON BRUSH HOLDER
A12	O RING	A38	CARBON BRUSH
A13	BIG GEAR	A39	SWIRL SPRING
A14	SPRING RETAINING WASHER 12	A40	SCREW ST3*10
A15	NEEDLE BEARING HK0808	A41	SCREW ST4*14
A16	SHAFT LOCK PIN	A42	RELIEF PLATE
A17	SCREW ST4*20	A43	CAPACITOR
A18	SPRING OF SHAFT LOCK	A44	SWITCH
A19	LOCK CAP	A45	SPRING FOR PULL LEVER
A20	HEAD CASE	A46	LEVER
A21	LOCKNUT M6	A47	REAR COVER
A22	SMALL GEAR	A48	CORD GUARD
A23	BALL BEARING 629-2RS	A49	CORD
A24	WASHER FOR BEARING	A50	SIDE HANDLE
A25	629 BEARING RETAINING COVER	A51	WHEEL
A26	SCREW M4*10	A52N	SPANNER

RU-ST20180605