



AG95125TE

NO.	DESCRIPTION	NO.	DESCRIPTION
1	WHEEL GUARD	27	ARMATURE
2	OUTER FLANGE	28	BAFFLE PLATE
3	INNER FLANGE	29	INSULATION WASHER
4	SPINDLE	30	BALL BEARING 607-2Z
5	WOODRUFF KEY	31	BEARING BUSH
6	DUSTPROOF RING	32	ST SCREW ST4*70
7	SCREW M4*14	33	STATOR
8	SPRING WASHER	34	BUTTON
9	FLAT WASHER	35	NAMEPLATE
10	BALL BEARING 6201-2RS	36	MOTOR HOUSING
11	FRONT COVER	37	CARBON BRUSH HOLDER
12	O RING	38	CARBON BRUSH
13	BIG GEAR	39	SWIRL SPRING
14	SPRING RETAINING WASHER 12	40	SCREW ST3*10
15	NEEDLE BEARING HK0808	41	SCREW ST4*14
16	SHAFT LOCK PIN	42	RELIEF PLATE
17	SCREW ST4*20	43	CAPACITOR
18	SPRING OF SHAFT LOCK	44	SWITCH
19	LOCK CAP	45	SPRING FOR PULL LEVER
20	HEAD CASE	46	LEVER
21	LOCKNUT M6	47	REAR COVER
22	SMALL GEAR	48	CORD GUARD
23	BALL BEARING 629-2RS	49	CORD
24	WASHER FOR BEARING	50	SIDE HANDLE
25	629 BEARING RETAINING COVER	52	SPANNER
26	SCREW M4*10	53	ELECTRONIC POWER CONSTAND SWITCH

AG95125TE-EX-RU240930

