



BP8704

NO.	DESCRIPTION
1	FRAME COMPONENTS
2	HEXAGONAL FACE BOLTS
3	FRAME VIBRATION DAMPING PADS
4	HEXAGONAL FACE BOLTS
5	KM170F-PUMP ENGINE
6	WATER PUMP COVER
7	SEAL PARTS
8	WATER PUMP IMPELLER
9	WATER PUMP CONNECTING DISK GASKET
10	IMPELLER CASING
11	PUMP BODY
12	STRAINER
13	STRAINER COVER
14	HOSE CLAMP PARTS (DOUBLE WIRE CLAMPS)
15	SCREW PLUGS
16	SCREW PLUG SEALING GASKET
17	OUTLET SEAT
18	OUTLET SEAT GASKET
19	HOSE COUPLING SEAL
20	HOSE FITTING NUT
21	HOSE CONNECTOR STRAIGHT PIPE
22	INLET SEAT GASKET
23	INLET SEAT
24	HEXAGONAL FACE BOLTS
25	HEXAGONAL FACE BOLTS

BP8704-EX-RUS221013

ENGINE FOR BP8704

NO.	DESCRIPTION	NO.	DESCRIPTION
1	THROTTLE RESET SPRING	44	HEXAGONAL FACE BOLTS
2	SPEED CONTROL BRACKET	45	CAMSHAFT PARTS
3	HEXAGONAL FACE NUTS	46	VALVE TAPPET
4	COTTER PINS	47	EXHAUST VALVE
5	PENDULUM	48	INTAKE VALVE
6	PENDULUM SHIM $\Phi 6.2 \times \Phi 15 \times 0.6$	49	CYLINDER HEAD GASKET
7	SPEED CONTROL TIE RODS	50	POSITIONING PINS
8	SPEED CONTROL SPRING	51	CYLINDER HEAD BOLTS
9	SPEED CONTROL BRACKET FIXING BOLTS	52	AIR FILTER
10	THROTTLE LEVER COMBINATION	53	AIR FILTER GASKET
11	HEXAGONAL FACE BOLTS	54	FUEL LINE CLAMP
12	PULL PLATE ASSEMBLY	55	OIL PIPE
13	HEXAGONAL FACE BOLTS	56	CARBURETOR PARTS
14	FLAME-OFF SWITCH	57	CARBURETOR GASKET
15	AIR GUIDE COVER (STARTER COVER)	58	CARBURETOR HEAT SHIELD
16	FLYWHEEL NUT	59	AIR INLET GASKET
17	STARTER CUP	60	DOUBLE-ENDED STUDS
18	FAN	61	CYLINDER HEAD
19	FLYWHEEL COMBINATION	62	DOUBLE-HEADED STUD
20	OIL SEAL	63	EXHAUST PORT GASKET
21	HEXAGONAL FACE BOLTS	64	MUFFLER PARTS
22	IGNITION COIL	65	HEXAGONAL FACE NUT
23	HEXAGONAL FACE BOLTS	66	CYLINDER BLOCK AIR GUIDE
24	LOWER SHIELD	67	SPARK PLUG
25	OIL DRAIN BOLT	68	VALVE TAPPET
26	OIL DRAIN BOLT GASKET	69	OIL RETAINER
27	OIL PROTECTOR	70	TAPPET LIMIT PLATE COMBINATION
28	CRANKSHAFT HOUSING	71	VALVE SPRING
29	LOCATING PIN $\Phi 8 \times 14$	72	INTAKE VALVE SPRING SEAT
30	DEEP GROOVE BALL BEARINGS	73	EXHAUST VALVE SPRING SEAT
31	OIL SENSOR	74	VALVE ADJUSTMENT CAP
32	HEXAGONAL FACE BOLTS	75	ROCKER ARM SHAFT BOLT
33	SPEED CONTROL GEAR PARTS	76	VALVE ROCKER ARM
34	CONNECTING ROD	77	VALVE ADJUSTING NUTS
35	CRANKSHAFT COMPONENTS	78	VALVE LOCK NUT
36	PISTON	79	CYLINDER HEAD COVER GASKET
37	PISTON PINS	80	CYLINDER HEAD COVER ASSEMBLY
38	PISTON PIN SNAP RING	81	FUEL TANK COVER
39	PISTON RING ASSEMBLIES	82	FUEL FILTER
40	CRANKCASE GASKET	83	FUEL TANK BODY
41	OIL DIPSTICK	84	FUEL OUTLET NOZZLE
42	CRANKCASE COVER	85	HEXAGONAL FACE BOLTS-EXTENDED SERIES
43	OIL PLUG		

BP8704-EX-RUS221013

