



Sturm!

нас рекомендуют друзья

CCS1867BL

NO.	DESCRIPTION	NO.	DESCRIPTION
1	M6 BOLT	40	POSITION RING 1
2	WASH	42	SCREW ST3.5X16
3	UP PLATE	43	SCREW ST4X20
4	BLADE	44	HOUSING
5	DOWN PLATE	45	SCREW M4X25
6	SHAFT RING	46	BEARING 607Z
7	PRESS PLATE	47	GEAR SHAFT
8	SCREW ST3X10	48	FIRST BIG GEAR
9	MOVABLE GUARD BUTTON	49	LED LIGHT
10	MOVABLE GUARD	50	PRESS LINE PLATE
11	SPRING	51	GEAR
12	SCREW M4X12	52	ROTOR
13	DUST PIPE	53	WIND RING
14	OUTSIDE FIX GUARD	54	STATOR
15	SCREW M4X10	55	PCB
16	INSIDE FIX GUARD	56	SWITCH
17	SCREW M5X16	57	SPRING
18	SCREW M5X38	58	SWITCH BUTTON
19	WASHER	59	BATTERY FOOT
20	SCREW M5X18	60	BASE
21	POSITION RING	61	RIVET
22	SCREW M5X8	62	SCREW M6X14
23	SHAFT	63	WASHER1
24	SCREW M4X18	64	WASHER2
25	GEAR BOX COVER	65	DEPTH RULER
26	BEARING 6900	66	DEPTH RULER POINT
27	BEARING PLATE	67	SCREW ST2.5X8
28	KEY	68	SCREW M6X12
29	SECOND BIG GEAR	69	DEPTH RULER TIGHT ROD
30	WASHER	70	SCREW M6X8
31	SHAFT RING	71	ANGLE RULER
32	NEEDLE HK0810	72	ADJUST BUTTON
33	PAPER	73	SPRING
34	SCREW M4X16	74	BUTTON OF RULER
35	PIN	75	SCREW M5X5
36	GEAR BOX	76	MARK
37	SPRING	77	GUIDE RULER
38	BUTTON	78	SPANNER
39	HANDLE		

CCS1867BL-EX-RUS20230808