


CD1655BLI[®]



NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	37	GEAR BOX
2	PRESS BOARD	38	PICK
3	TORQUE RING	39	PICK
4	TORQUE NUT	40	THE FIRST INNER GEAR RING
5	SPRING	41	GREASE SEAL(L)
6	FUNCTION RING	42	GEAR BOX COVER
7	ADJUST GASKET	43	MOTOR GEAR
8	TORQUE GASKET	44	TWO SPEED CHANGE SPRING
9	BUSH	45	GREASE SEAL(R)
10	SPINDLE	46	REAR COVER
11	BRARING 6801	47	ROTOR
12	UPPER IMPACT GEAR	48	STATOR
13	IMPACT GASKET	50	HOUSING
14	SPRING	51	TWO SPEED CHANGE BUTTON
15	LOWER IMPACT GEAR	52	LEFT SCREW
16	PIN	53	CHUCK
17	IMPACT PANEL	54	DIRECTION LEVER
18	BEARING 6800	55	SWITCH
19	RUBBER RING	56	FUNCTION BUTTON
20	THE FIRST PLANET GEAR	57	LED COVER
21	NEEDLE	58	CONTROLLER
22	THE SECOND PLANET CARRIER	59	BATTERY PACK
23	GEAR RING	60	CHARGER
24	THE SECOND PLANET GEAR	888	GEAR BOX ASSEMBLY
25	THE THIRD PLANET CARRIER		
26	PIN		
27	GEAR POSITION WASHER		
28	BIG WASHER		
29	THE THIRD PLANET GEAR		
30	INNER GEAR RING		
31	PLANET CARRIER		
32	PIN		
33	AXLE LOCK		
34	PIN		
35	SCREW		
36	INNER GEAR WASHER		

CD1655BLI-EX-RU240816-1

Sturm!
нас рекомендуют друзья