




CD3212L CD3214L

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	CHUCK SCREW	A25	MOVING GEAR RING
A2	CHUCK	A26	GEAR BOX BUSH
A3	BIG CIRCLIP	A27	UPPER GEAR RING
A4	TORQUE ADJUSTMENT PIECE	A28	THE FIRST PLANET CARRIER
A5	TORQUE ADJUSTMENT RING	A29	THE FIRST PLANET GEAR
A6	TORQUE ADJUSTMENT NUT	A30	WASHER
A7	SPRING	A31	SCREW
A8	BIG WASHER	A32	MOTOR COVER
A9	PIN	A33	MOTOR GEAR
A10	STEEL BALL	A34	MOTOR
A11	SPINDLE	A35	TWO SPEED CHANGE BUTTON
A12	BEARING 689Z	A36	SPRING
A13	TORQUE ADJUSTMENT SPRING	A37	RIVET
A14	GEAR BOX	A39	DIRECTION CHANGLE LEVEL
A15	TWO SPEED CHANGE SPRING	A40	SWITCH
A16	GEAR BOX PIN	A41	BATTERY CONNECTION FOOT
A17	CIRCLIP	A42	SLING
A18	WASHER	A44	SCREW
A19	INNER GEAR RING	A45	BATTERY PACK
A20	THE THIRD PLANET CARRIER	A46	CHARGER
A21	THE THIRD PLANET GEAR	A100	GEAR BOX ASSEMBLY
A22	WASHER	A101	MOTOR ASSEMBLY
A23	THE SECOND PLANET CARRIER	A888	HOUSING ASSEMBLY
A24	THE SECOND PLANET GEAR		

ST-RU20151222 VER: 2.1