




COS18125

NO	DESCRIPTION
1	HOUSING
2	DAMPING PILLAR
3	DUST COVER OF SWITCH
4	SWITCH
5	SPEED PCB
6	BRUSHLESS MOTOR STATOR
8	SCREW ST3.9X17
9	BATTERY LEAD PLATE
10	CONTROL PCB
11	BEARING 608RS
12	BRUSHLESS MOTOR ROTOR
13	BEARING 607RS
14	BALANCE FAN
15	BEARING HOLDER
16	DUST PROTECT WASHER
17	BEARING 6002RS
18	WASHER
19	SPRING WASHER M5
20	SCREW M5X14
21	BRAKE RING
22	PRESSURE PLATE
23	BASE PLATE
24	WASHER M5
25	SPRING WASHER M5
26	SCREW M5X12
27	SCREW ST2.9X8
28	DUST ADAPTOR
29	DUST OUTLET
30	DUST OUTLET STEEL WIRE
31	DUST BAG

COS18125-EX-RU240320