


# CRH1825BL



NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SLEEVE ASSEMBLE	6-1	PISTON	23-1	STATOR
1-1	DUST CAP	6-2	PISTON RING	23-2	COVER
1-2	SLEEVE RING	6-3	CYLINDER	23-3	UP COVER
1-3	SLEEVE	6-4	U WASHER	23-4	SCREW ST2.2×10
1-4	SLEEVE WASHER	6-5	CYLINDER PIN	23-5	SWITCH
1-5	BALLØ7.14	7	SURPORT ASSEMBLE	23-6	PCB
1-6	SLEEVE WASHER1	7-1	SURPORT SLEEVE	23-7	LINE 260
1-7	COMPRESS SPRING	7-2	SURPORT	23-8	BATTERY FOOT
2	SCREWST4.8×40	7-3	OIL WOOL	24	RUBBER
3	HOUSING ASSEMBLE	7-4	GEAR BOX PIN	25	BEARING BOARD
3-1	HOUSING	7-5	629 RING	26	HANDLE ASSEMBLE
3-2	OIL SEAL	7-6	BEARING 629	26-1	STEEL RING
3-3	BEARING 6805	7-7	PRESSURE BOARD	26-2	T SCREW
3-4	NEDDLE BEARING HK0709	7-8	SCREW M4×10	26-3	BUTTON
3-5	12 WASHER	8	MIDDLE SHAFT ASSEMBLE	26-4	HANDLE SEAT
3-6	SCREWM4×10	8-1	MIDDLE SHAFT	26-5	NUT
4	BUTTON ASSEMBLE	8-2	BEARING 699	26-6	HANDLE
4-1	SMALL BUTTON	9	ADJUST FORK	27	RULER
4-2	BUTTON SPRING	10	FORK SPRING	28	SURPOT SEAL
4-3	ADJUST BUTTON	11	YAW BEARING AND 0908	29	BEARING WASHER
4-4	BUTTON O RING	11-1	HK0908		
5	ROTATING SLEEVE ASSEMBLE	11-2	YAW BEARING		
5-1	ROTATING SLEEVE RING	12	CLUTCH		
5-2	ROTATING SLEEVE WASHER	13	SURPORT SPRING		
5-3	ROTATING SLEEVE SPRING	14	GEAR ASSEMBLE		
5-4	BIG GEAR	14-1	GEAR		
5-5	LIMIT RING	14-2	BEARING 607Z		
5-6	LIMIT PIN	15	SCREW M4×12		
5-7	ROTATING SLEEVE	16	4 WASHER		
5-8	IMPACT ROD RING	17	YAW PRESSURE BOARD		
5-9	IMPACT ROD	18	LIGHT COVER		
5-10	IMPACT ROD SLEEVE RING	19	SCREW ST3.9×16		
5-11	LIMIT SLEEVE	20	HOUSING		
5-12	LIMIT SLEEVE O RING	21	BUTTON		
5-13	ROTATING SLEEVE INNER RING	22	ROTOR		
6	CYLINDER ASSEMBLE	23	STATOR ASSEMBLE		